

Gunki Main Boom for Belly Boat



The main boom can be attached to the right or left side of the belly boat at the provided rings, where it is securely fastened and holds your accessories. It is the basis for all other accessories for the Gunki belly boats (storage table, rod holder, echo holder, etc.).

* incl. tax, plus shipping